

- e. Tighten the anchor bolt nuts to a snug fit with full bearing on the base of the post.
- f. When posts and rails are completely bolted into place, ensure that they are true to line and grade.

516.3.06 Quality Acceptance

General Provisions 101 through 150.

516.3.07 Contractor Warranty and Maintenance

General Provisions 101 through 150.

516.4 Measurement

This work will be measured for payment in linear feet (meters) of accepted handrail. Handrail will be measured along the top rail from out-to-out of ends of aluminum rail or from out-to-out of aluminum end posts, whichever is greater. No deductions will be made for openings at deck expansion joints or at light standards.

516.4.01 Limits

General Provisions 101 through 150.

516.5 Payment

This work will be paid for at the Contract Price per linear foot (meter) for aluminum handrail complete in place.

Payment will be made under:

Item No. 516	Aluminum Handrail, (<u>Type</u>)	Per linear foot (meter)
--------------	------------------------------------	-------------------------

516.5.01 Adjustments

General Provisions 101 through 150.

Section 517—Protective Concrete Collar for Existing Columns

517.1 General Description

Specifications for this work will be included elsewhere in the Contract.

Section 518—Raise Existing Bridge

518.1 General Description

Specifications for this work will be included elsewhere in the Contract.

Section 519—Concrete Bridge Deck Overlay

519.1 General Description

Specifications for this work will be included elsewhere in the Contract.

Section 520—Piling

520.1 General Description

This work consists of placing completed piling in structures. The work includes incidentals and additional work except for the following:

- Prestressed concrete cylinder piling (see Project Special Provisions)